


Troubleshooting Game Timer

If you are having trouble connecting to the Game Timer, try one of the following:

- A.** Insure the game timer is **plugged into an electrical outlet**
- B.** Turn **off**, then **on** your mobile device's Bluetooth setting 
- C.** Turn **off**, then **on** your mobile device
- D. Factory Reset:** plug and unplug the game timer 6 times in a row. It will beep 3 times indicating that it has reset

Now, try to connect to the timer again.

If still unsuccessful, please email:

info@funtimevolleyball.com